

User Manual

Flow Meter –
Thermal Mass
(Outdoor, Insertion)

Model: FLO



Table of Contents

- Notices and Warnings 3
- Introduction 5**
 - About Flow Meters 6
 - Intended use 6**
 - Specifications 7
 - Compressed Air Alliance App 9
 - Flow Meter Pack 10
- Installation 11**
 - Installation Overview 12
 - Installation – Mechanical 13
 - Installation – Electrical 24
 - Configuring the Flow Meter 26
 - Modbus Settings 29
- Using the Flow Meter 32**
 - Operating the Flow Meter 33
 - Using the Display 34
- Trouble Shooting 38**
 - Trouble Shooting 39
 - Default / Factory Settings 42
 - Warranty 43
 - Calibration 43

Notices and Warnings

Notices

Please **read all of this manual** before you install, operate or maintain this product. Pay attention to notes, warnings and instructions. The manufacturer cannot be held liable for any damage that occurs as a result of noncompliance with this manual.

Do not tamper with device. Should the device be tampered with in any manner other than a procedure which is described and specified in this manual, the warranty is cancelled and the manufacturer is exempt from liability.

The product is designed exclusively for the described application. Use of this product in conditions not specified in this manual or, contrary to the instructions provided by the manufacturer, is considered improper handling / use of the product and will void your warranty. The manufacturer will not be held liable for any damages resulting from improper use of the product.

This manual should be read carefully by relevant personnel and the end user. This manual should be kept with the product and be made available as needed. **Once you install or use the product, you accept that you have read, understood and complied with this manual.**

Compressed Air Alliance endeavours to make the content of this manual correct, but is not responsible for omissions or errors and the consequences caused. In case of any doubts or questions regarding this manual or the product, please contact Compressed Air Alliance.



Warnings

Ignoring the warnings can lead to serious injury and/or cause damage!

When handling, operating or carrying out maintenance on this product, personnel must employ safe working practices and observe all local health & safety requirements and regulations.

Improper operation or maintenance of this product could be dangerous and result in an accident causing damage to machinery or personal injury or death.

The manufacturer cannot anticipate every possible circumstance which may represent a potential hazard. The warnings in this manual cover the most common potential hazards and are therefore not all-inclusive. If the user employs an operating procedure, an item of equipment or a method of working which is not specifically recommended by the manufacturer they must ensure that the product will not be damaged or made unsafe and that there is no risk to persons or property.

NEVER CHANGE ORIGINAL COMPONENTS WITH ALTERNATIVES.



Compressed Air Safety

Any contact with quickly escaping air or bursting parts of the compressed air system can lead to serious injuries or even death.

Do not exceed the maximum permitted pressure.

Only use pressure rated installation materials and parts.

Avoid getting hit by escaping air or bursting parts.

The system must be pressure-less during maintenance work.



Electrical Safety

Any contact with energised parts of the product may lead to an electrical shock which can lead to serious injuries or even death. The user shall take all measures necessary to protect against electrical shock.

Follow regulations for electrical installations.

The system must be disconnected from any power supply during maintenance work.

Any electrical work on the system is only allowed by authorised qualified personal.

Storage and transportation

Make sure that the transportation temperature of the sensor is between -10°C to 60°C (14°F to 140°F).

Please make sure that the storage temperature of the sensor is between -10°C to 50°C (14°F to 122°F) and the humidity is $<90\%$, no condensation.

Avoid direct UV and solar radiation during storage.

Cleaning


If you need to clean the sensor it is recommended to use a clean, dry cloth. For stubborn marks, use distilled water or isopropyl alcohol only.

Please note: contamination on the sensor tip will affect calibration and accuracy of the sensor. Removal of the contamination may not fix the issue.

Disposal

Electronic devices are recyclable material and do not belong in the household waste. The product, accessories and its packing material must be disposed according to local statutory requirements.

Introduction



About Flow Meters

Intended use

Compressed Air Alliance's flow meters are suitable for use in manufacturing, industrial and base building environments providing the sensors specifications are met. This includes:

Sensor is used in inert gases, eg air, oxygen, nitrogen, carbon dioxide

Sensor is used in clean, dry gas

Gas flow rate is between 0.1 to 250 Nm/s (0.3 to 820 ft/sec)

Gas pressure is between 0 to 50 bar (725 psi)

Gas temperature is between -40°C to +150°C (-40°F to +302°F)

Power supply is between 18 to 30 vDC

The flow meter is **not** used in explosive environments.

Refer to the *Specifications* section (next page) for full requirements.

The thermal mass flow meter measures standard flow, mass flow, consumption and temperature.

Thermal Mass Flow Meters

Thermal Mass flow sensors are perfectly suited for measuring clean, dry compressed air and inert gases. The streamlined sensor tip is designed to ensure minimal impact on gas flow while maintaining accuracy over a wide flow range.

Compressed Air Alliance's thermal mass flow meter measures standard flow, mass flow, consumption and temperature. It has full digital signal processing instead of traditional analog bridge design, making the flow meter more accurate and able to measure across a wider range.

Thermal mass flow meters are widely used in industrial processes, chemical, petrochemical, power engineering, etc. They are suitable for temporary or permanent installations.

Our thermal mass flow meters are available as insertion style or inline style.

insertion type sensors which are easy to install under pressure through a 1/2" ball valve.


inline type sensors are more suited to permanent installations or where shutting down the system to calibrate the sensor is not an issue.

Specifications

Thermal Mass Flow Meter - Insertion		
Technology	Thermal mass, Insertion design	
Application	Manufacturing and Industry	
Gases	Air, Argon, Carbon Dioxide, Helium, Hydrogen, Natural Gas, Nitrogen, Nitrous Oxide, Oxygen	
Gas Quality	Clean and dry gas	
Accuracy	$\pm(1.5\% \text{ reading} + 0.3\% \text{ full scale})$ <i>Accuracy is affected by the installation location, on-site conditions and contaminants such as oil, high humidity or other impurities</i>	
Measurement Ranges		
Flow Measurement	0.1 to 250 Nm/sec	0.3 to 820 ft/sec
Pressure Measurement	0 to 50 bar (725 psi) (installation device required for over 16 bar / 232psi)	
Gas Temperature Measurement	-40°C to +150°C	40°F to +302°F
Outputs		
Output	Analog: 4 to 20mA / Pulse output Digital: RS485 Modbus / RTU	
Output Signals	Flow, mass flow, consumption and temperature	
Power		
Power Supply	18 to 30VDC / 5W@24V	
Electrical Connection	Terminal Strip	
EMC	According to IEC 61326-1	
Display		
Display	2.8" LCD with touch panel	

Other Information		
Bi-directional	No	
Data Logger	No	
Pipe Size	DN20 to DN300	
Shaft Lengths	250 mm or 400 mm	9.8" or 15.7"
Process Connection	ISO G1/2" thread	
Ambient Temperature	-30°C to +70°C	-22°F to +172°F
Installation Type	Permanent or temporary installation	
Calibration Frequency	Every 2 years <i>provided the sensor is not exposed to relative humidity above 85%</i>	
Warranty Period	12 Months	
Reference Conditions	20°C, 1bar(a), ISO1217	

Dimensions (mm)



Flow Range

Pipe Size		Flow Range (Nm ³ /h)		Flow Range (cfm)	
DN	ID (inches)	Min Flow	Max Flow	Min Flow	Max Flow
20	0.75"	0.1	282	0.1	166
25	1"	0.2	441	0.1	259
32	1.25"	0.3	723	0.2	425
40	1.5	0.5	1,131	0.3	665
50	2"	0.7	1,767	0.4	1,040
65	2.5"	1.2	2,986	0.7	1,757
80	3"	1.8	4,523	1.1	2,661
100	4"	2.8	7,068	1.6	4,158
125	5"	4.4	11,044	2.6	6,498
150	6"	6.4	15,904	3.8	9,357
200	8"	11.3	28,274	6.6	16,635
250	10"	17.7	44,178	10.4	25,991

Compressed Air Alliance App

Flow Meter App - View data and edit settings on your phone

The Compressed Air Alliance App allows you to view data and check / update settings on your phone.

This feature is great for viewing flow readings when your flow meter is installed in high locations.

Contact Compressed Air Alliance or your local dealer for more information.



Flow Meter Pack

Each flow meter pack comes with:

- ✓ 1 x Thermal Mass Flow Meter – Insertion style, configured for your gas type.
- ✓ 1 x O-Ring
- ✓ 1 x Adjustment tool (used to align flow meter correctly)
- ✓ Calibration Certificate

Flow Meter Pack



Flow Meter



O-Ring



Adjustment tool

Installation



Installation Overview

Mechanical Installation

Step 1 – Find a suitable section of pipe

The sensor must be installed vertically or horizontally, in clean, dry gas
The sensor must be installed away from bends, edges, seams, changes in pipe size and other obstructions

Do **NOT** install the sensor in wet gas or upside down

Step 2 – Install connection point, eg ball valve or nipple

Step 3 – Fit flow meter

Step 4 – Align sensor with direction of gas flow

Electrical Installation

Step 5 – Wire the sensor for 24vDC power and communication

Sensor Configuration

Step 6 – Set sensor settings:

Inner Pipe Diameter

Unit of Measurement

Communication settings (RS485 or Analog)

Optional – Confirm other sensor settings

Step 7 (optional) – Connect the sensor to your SCADA or energy management system

Tools and Equipment needed for installation

(not included with Flow Meter Pack)



Wrench /
Spanner



Screw Driver



Ball Valve
(optional)



Thread Tape /
Sealant

Installation – Mechanical



WARNING! Incorrect installation can damage the sensor or cause it to work incorrectly.



Notes

Before installing the sensor, make sure it is rated for your system (refer to the “Specifications” section).

- Use of the product outside specified ranges or operating parameters can lead to malfunctions and may damage the product or system.

Do **not** use this product in explosive areas.

Pay attention to the installation location and gas contamination levels to ensure accuracy is maintained.

The flow meter is **not** bidirectional. When installing and using the flow meter, please pay attention to the direction of gas flow and the alignment of the sensor. The flow direction is indicated on the housing.

Avoid condensation on the sensor element as this will affect the accuracy enormously.

The sensor can be used indoor or outdoor.

Only use pressure rated materials and parts when installing and maintaining the product.

Do not disassemble the product.

Please follow local and national regulations before/during installation and operation.

This product must be installed properly and calibrated regularly, otherwise it may lead to inaccurate measurements.


Step 1 – Find a suitable section of pipe

The sensor **must** be installed:

- ✓ at 90° to the pipe, +/- 15° (ie within 75° to 105°).
- ✓ vertically or horizontally,
- ✓ away from bends, edges, seams, changes in pipe size and other obstructions,
- ✓ in dry gas (gas humidity should be less than 80% relative humidity (RH)).
- ✓ in clean gas (the sensor should be inserted after filters and dryers)


Make sure the insertion location has enough room around the pipe to install the sensor.

Install 90° (perpendicular) to pipe






Correct Installation



Incorrect Installation

Do **NOT** install the sensor in wet gas
Do **NOT** install the sensor upside down or at an angle. This can result in water accumulating in the shaft or head of the sensor. This can damage the sensor and void the warranty.



Choose insertion location, away from obstacles

To achieve and maintain the accuracy stated in the specifications, the sensor must be inserted away from bends, edges, seams, curves, changes in pipe size, control valves, etc.

For best results choose a long, absolutely straight, section of pipe that is free of obstructions.

Pipe obstructions (eg bends, edges, seams, curves, changes in pipe size, control valves, etc) change the velocity of compressed air / gasses and/or create turbulence near the obstruction. Placing the sensor too close to the obstruction will result in inaccurate readings.



Notes

Pay attention to the distance between the sensor's inlet and outlet sections and points of turbulence (eg bends, valves, etc).

Make sure that the insertion location has enough straight pipe on either side of the sensor, as shown in the diagrams below.


Obstructions can cause counter-flow turbulence as well as turbulence in the direction of the flow. Turbulence will reduce the accuracy of flow readings and result in inaccurate data.




Correct Installation

The diagram below shows the **minimum** allowable distance between the sensor and any bends, changes in pipe size or other obstructions. Distances are shown in multiples of pipe diameters (DNs). For best results, choose a long, absolutely straight section of pipe that is free of obstructions.


1 Reduction




2 Expansion




3 90° Bend or Tee




4 2 x 90° Bends




5 2 x 90° Bends (3 dimension)



6 Valve or Regulator





Examples



To install a flow meter near 2 x 90° bends, you need at least 30 DN of space (25 DN on the inlet side + 5 DN on the outlet side, see diagram 4 on previous page)
 Only 20 DN is available.
 Therefore, the sensor should **not** be installed in this location

To install a flow meter near a control valve or pressure regulator, you need at least 55 DN (50 DN on inlet side and 5 DN on outlet side, see diagram 6 on previous page)
 This section of pipe has 65 DN on the inlet side and 5 DN on the outlet side
 Therefore, the sensor **can** be installed in this location



A flow sensor will be installed on a section of pipe, just after a bend (as shown in the diagram on the left). The pipe has a DN of 50 (ie, it's a 2 inch or 50 mm pipe).

Therefore, the sensor must be installed:

Inlet side: 20 x DN from the bend
 = 20 x 2" = 40" or
 = 20 x 50mm = 1,000mm = 1 meter

Outlet side: 5 x DN from any other obstruction
 = 5 x 2" = 10" or
 = 5 x 50mm = 250mm

Step 2 – Install connection point

To install the sensor, you need a connection point on the pipe, eg a ball valve or a nozzle or nipple. The thread must be G 1/2".


Use of a ball valve is optional - You do not need to use a valve to install the sensor. However, using a valve will make removing the sensor easier (eg when you need to remove the sensor for calibration).

If installing a ball valve, you can use a hot tap drill and clamp to create a connection point on pressurized or unpressurized pipes. See the Compressed Air Alliance website for information on hot tap drills and clamps.



Ball Valve
(full bore)

OR



Welded nipple on pipe


Step 3 - Fit Flow meter

Place O-Ring on sensor shaft gland nut.

Wrap thread tape / sealant tape around sensor thread. Do not let tape enter pipe.

Screw the sensor into the connection point.

If using a ball valve, open the valve.




Use the depth scale on the sensor shaft to place the tip of the sensor in the middle of the pipe.

Once the tip is in the centre of the pipe, tighten the gland nut to hold the sensor in place.

$$\text{The Insertion Depth} = x + y = \frac{OD}{2} + y.$$

Where OD = outer diameter of pipe and Y = ball valve height.




Example

A flow meter is being installed in a cooper tube with a DN of 100. This equates to an outer diameter (OD) of 100 mm. The ball valve is 87 mm high.


The Insertion Depth = $OD/2 + y$
where y = height of the ball valve.

Therefore, the Insertion Depth =
 $100 \text{ mm} / 2 + 87 \text{ mm} = 50 \text{ mm} + 87 \text{ mm} = 137 \text{ mm}.$




Correct Installation

The sensor tip must be in the center of the pipe / tube.



Incorrect Installation

Note: Inaccurate measurement may occur if the sensor is installed incorrectly.




Step 4 – Align sensor with the direction of flow

The flow meter is **not** bidirectional. When installing and using the flow meter, please pay attention to the direction of gas flow and the alignment of the sensor.

The direction of flow is marked by 4 arrows on the front of the sensor head.



Use the alignment tool to align the sensor with the pipe. Ensure the arrows on the sensor match the direction of flow.



Installation – Electrical



WARNING! Incorrect wiring can damage the sensor or cause it to work incorrectly.

Notes:


Follow all local and national safety requirements and regulations for electrical installations.

The system must be disconnected from any power supply during installation and maintenance work.

Any electrical work on the system is only allowed by authorised and qualified personnel.

Compressed Air Alliance recommends the use of bootlace terminals


Step 5 - Wire the sensor for 24vDC power & communication




Wiring for Flow Meter with Inbuilt Display

4-20mA Scaling
 4mA = 0
 20mA = 250

Signals = Flow, Velocity,
 or Temperature




Wiring for Flow Meter with Separate / Split Display



Bu = Data -
Au = Data +

Configuring the Flow Meter

Step 6 - Set sensor settings



Scroll up and down to see more options

Tap to select that menu



Scroll left and right to see more options

Scroll up and down to select the number. (Selected number is on the middle row)

You must configure the flow meter to make sure it is reading accurately.

You **must** set the (inner) pipe diameter.

You should check / adjust the gas type, units of measure, communication settings (4-20mA and/or Modbus) and screen rotation.

Mandatory Configuration - Pipe Diameter



Pipe diameter refers to Inner Pipe diameter. **Not** the outer diameter.

To set the inner pipe diameter:

Go to **Settings** () > **Pipe Diameter**.

Enter new **inner** diameter of the pipe, in millimeters (mm)

- You will need to swipe left and right to see all options
- You will need to scroll up and down to select the number.

Press the arrow () to save your settings and return to the previous screen.

Optional configuration

We recommend you check the following settings on the flow meter. See the next section - "Using the Display" for instructions on checking / updating settings.

Gas type

Unit of Measurement

Communication settings (RS485 or Analog)

Modbus Settings

Default Settings

Default Modbus RTU (RS485) Settings					
Address	Baud Rate	Frame / Parity / Stop Bit	Response Time	Response Delay	Frame Spacing
1	9600	8 / N / 1	1 Sec	0 ms	7 Characters

Modbus Registers

Settings can be changed to suit system requirements. **Note:** These settings will take effect after writing a "1" to the holding register address 50. Then Modbus master must change communication settings accordingly in order to communicate with the slave.

Holding register definition

- Modbus read command: 0x03
- Modbus write command: 0x06 for single register, 0x10 for multiple register
- Coil registers write command: 0x05

Byte Order

Data is little end, and least significant bit transmitted first

32bit: CD AB

64bit: GH EF CD AB

Registers					
Holding Register Address	Data Type	Byte Length	Data / Description	Comments	Read / Write
0	FLOAT_L	4	Flow		Read
2	FLOAT_L	4	Velocity		Read
4	DOUBLE_L	8	Consumption	Write "0" to clear value	Read/

Registers					
Holding Register Address	Data Type	Byte Length	Data / Description	Comments	Read / Write
					Write
8	FLOAT_L	4	Temperature		Read
22	UNSIGNED LONG	4	Consumption	4 byte valve type Write "0" to clear value	Read/ Write
26	UNSIGNED INT	2	Gas Type	0 = Air (Default) 1 = Oxygen (O2) 2 = Nitrogen (N2) 3 = Hydrogen (H2) 4 = Carbon monoxide (CO) 5 = Carbon dioxide (CO2) 6 = Sulfur hexafluoride (SF6) 7 = Argon (Ar) 8 = Helium (He) 9 = Nitrous oxide (N2O) 10 = Methane (CH4) 11 Ethane (C2H6) 12 Propane (C3H8) 13 Butane (C4H10)	Read/ Write
27	UNSIGNED INT	2	Flow Unit	0 = m ³ /h (Nm ³ /h) 1 = m³/min (Nm³/min) (Default) 2 = m ³ /s (Nm ³ /s) 3 = l/min (Nl/min) 4 = l/s (Nl/s) 5 = cfm (Ncfm) 6 = kg/h 7 = kg/min 8 = kg/s	Read/ Write
28	UNSIGNED INT	2	Velocity Unit	0 = m/s (Nm/s) (Default) 1 = ft/s (Nft/s)	Read/ Write
29	UNSIGNED INT	2	Consumption Unit	0 = m³ (Nm³) (Default) 1 = ft ³ (Nft ³) 2 = kg	Read/ Write
30	UNSIGNED INT	2	Temperature Unit	0 = °C (Default) 1 = °F	Read/ Write

Registers					
Holding Register Address	Data Type	Byte Length	Data / Description	Comments	Read / Write
32	FLOAT_L	4	Pipe Inner Diameter		Read/
50	UNSIGNED INT	2	Restart device Write "1" to restart device		Write
51	UNSIGNED INT	2	Device address	Range = 1-247 Default = 1	Read/ Write
52	UNSIGNED INT	2	Baud Rate (bps)	12 = 1200 24 = 2400 48 = 4800 96 = 9600 (Default) 144 = 14400 192 = 19200 384 = 38400 560 = 56000 576 = 57600 1152 = 115200	Read/ Write
53	UNSIGNED INT	2	Parity	0 = None (Default) 1 = Odd 2 = Even	Read/ Write
54	UNSIGNED INT	2	Stop Bit	1 = 1 bit (Default) 2 = 2 bit	Read/ Write
55	UNSIGNED INT	2	Response Time Out	Range = 0 to 255 ms in 1 ms/step Default = 0 ms	Read/ Write

Using the Flow Meter



Operating the Flow Meter



WARNING! Make sure the sensor is installed and wired correctly before powering up the sensor. Only use 24vDC to power the sensor.


Turning On

Connect the flow meter to 24vDC power. The sensor will start powering up automatically. There is no on/off switch on the sensor.

On powering up:


The Compressed Air Alliance logo will appear on the screen.

After a few seconds, you will see flow meter home screen. The flow meter is now ready to configure (see next page).



Flow Meter home screen. The sensor is ready to configure

Using the Display



Scroll up and down to see more options

Tap to select that menu



Scroll left and right to see more options

Scroll up and down to select the number. (Selected number is on the middle row)


Menu Options

Menu	Sub Menus	Options / Comments														
Pipe Diameter	-	Set inner pipe diameter. This must be set when you install the flow meter														
Unit Settings	Flow Unit	<table> <tr> <td>m³/h</td> <td>l/min</td> <td>Kg/h</td> </tr> <tr> <td>m³/min</td> <td>l/s</td> <td>Kg/min</td> </tr> <tr> <td>m³/s</td> <td>cfm</td> <td>Kg/s</td> </tr> </table>	m ³ /h	l/min	Kg/h	m ³ /min	l/s	Kg/min	m ³ /s	cfm	Kg/s					
	m ³ /h	l/min	Kg/h													
	m ³ /min	l/s	Kg/min													
	m ³ /s	cfm	Kg/s													
Velocity Unit	<table> <tr> <td>m/s</td> <td>ft/s</td> </tr> </table>	m/s	ft/s													
m/s	ft/s															
Consumption Unit	<table> <tr> <td>m³</td> <td>ft³</td> <td>kg</td> </tr> </table>	m ³	ft ³	kg												
m ³	ft ³	kg														
Temperature Unit	<table> <tr> <td>°C</td> <td>°F</td> </tr> </table>	°C	°F													
°C	°F															
Medium Type	-	<table> <tr> <td>Air</td> <td>Nitrous oxide (N2O)</td> </tr> <tr> <td>Argon (Ar)</td> <td>Oxygen (O2)</td> </tr> <tr> <td>Carbon dioxide (CO2)</td> <td>Sulfur Hexa (SF6)</td> </tr> <tr> <td>Carbon monoxide (CO)</td> <td>Methane (CH4)</td> </tr> <tr> <td>Helium (He)</td> <td>Ethane (C2H6)</td> </tr> <tr> <td>Hydrogen (H2)</td> <td>Propane (C3H8)</td> </tr> <tr> <td>Nitrogen (N2)</td> <td>Butane (C4H10)</td> </tr> </table>	Air	Nitrous oxide (N2O)	Argon (Ar)	Oxygen (O2)	Carbon dioxide (CO2)	Sulfur Hexa (SF6)	Carbon monoxide (CO)	Methane (CH4)	Helium (He)	Ethane (C2H6)	Hydrogen (H2)	Propane (C3H8)	Nitrogen (N2)	Butane (C4H10)
	Air	Nitrous oxide (N2O)														
Argon (Ar)	Oxygen (O2)															
Carbon dioxide (CO2)	Sulfur Hexa (SF6)															
Carbon monoxide (CO)	Methane (CH4)															
Helium (He)	Ethane (C2H6)															
Hydrogen (H2)	Propane (C3H8)															
Nitrogen (N2)	Butane (C4H10)															
		Note: The flow meter is calibrated in air. If you select another gas type, the flow meter will automatically adjust its readings to match the gas selected. If you require calibration in real gas, contact Compressed Air Alliance or your local dealer														
Normalisation	Temperature	<p>The Normalization screen lets you change the reference conditions of the flow meter. The Flow Meter will readjust its calculations to suit the new normalization valves.</p> <p>The normalization setting should only be changed if the flow meter is installed under conditions that differ from the</p>														
	Pressure															

Menu	Sub Menus	Options / Comments	
		standard calibration (20°C, 1 bar, 0% relative humidity). Default Values: Temperature = 20°C Pressure = 100.00kPa	
RS485 Settings		Options	Default Settings
	Device Address	1 to 247	1
	Baud Rate	1200 2400 4800 9600 14400 19200 38400 56000 57600 115200	9600
	Parity	None Odd Even	None
	Stop Bits	1 2	1
	Response Delay	0 to 999 ms	0
Analog output		Options	Default Settings
	4-20mA Channel	Flow Velocity Temperature	Velocity
	4-20mA Scaling Low	±0 to ±99999999.99	0.00 Nm/s

Menu	Sub Menus	Options / Comments	
	4-20mA Scaling High	±0 to ±9999999.99	250.00 Nm/s
	Pulse Settings	1m ³ /Pulse 5m ³ /Pulse 10m ³ /Pulse	5m ³ /Pulse
System Settings	Brightness	View / change screen brightness	
	Screen Timeout	View / change timing for screen lock from 15 seconds to 10 minutes	
	Language	Change language – English or Chinese	
	System information	<p>Power Up Times: Number of times the sensor has been disconnected and reconnected to power</p> <p>Sensor Information: Serial Number, hardware version and software version</p> <p>Display Information: Serial Number, hardware version and software version</p>	
Advanced Settings		<p>These settings are password protected. They should not be changed as they will affect the flow meter readings and accuracy. Advanced settings let you change:</p> <ul style="list-style-type: none"> Velocity Offset Ratio Consumption Cut Off Velocity <ul style="list-style-type: none"> ○ This is the minimum velocity the flow meter can detect. If the flow is less than the cut off velocity, the flow meter will read '0'. The flow meter is not calibrated for velocities less than 0.1m/s. Velocity Filter Grade Change Password 	

Trouble
Shooting



Trouble Shooting


Problem	Possible Causes	Suggested Action
Readings are different than expected	Flow meter installed incorrectly, eg upside down, too close to bends	<p>Check installation</p> <p>Is the flow meter at 90° to pipe</p> <p>Is flow meter upside down?</p> <p>Is flow meter too close to bends, obstructions, etc?</p> <p>Is the sensor tip in the centre of the pipe?</p> <p>Do the arrows on the flow meter head match the direction of gas flow?</p>
	Flow meter is wired incorrectly	Check Wiring
	Flow meter not configured for system	<p>Check / update the following settings:</p> <p>Inner Pipe diameter (not outer diameter)</p> <p>Unit of Measurement</p> <p>Gas Type</p> <p>Communication settings (RS485 or Analog)</p>
	Gas is off	<p>Turn gas on.</p> <p>Open isolation valves</p>
	Normalization data has changed	<p>Reset normalisation to factory default:</p> <p>Temperature = 20°C</p> <p>Pressure = 100 kPa.</p>
	Flow meter is due for calibration	Calibrate sensor. Compressed Air Alliance can help with calibration

Problem	Possible Causes	Suggested Action
---------	-----------------	------------------

	Incorrect flow meter for your system	Check that the sensor's specifications are suitable for your system.
--	--------------------------------------	--

The touch screen isn't working	You are using hard objects to operate the display, eg fingernails, pens	Use the fleshy part of your finger to touch the screen. The touch screen does not work if you use finger nails or pens.
--------------------------------	---	---


I can't see all menu items	On some menus, you will need to scroll up and down (or left and right) to see all items.	
----------------------------	--	--



I can't access the CAA App	Trying to use App on iPhone	The CAA App only works on Android phones.
----------------------------	-----------------------------	---

	Update needed	Contact your local distributor or CAA to get the latest version of the CAA App
--	---------------	--

The screen is in the wrong language	Step 1 – Select the Settings icon Step 2 – Scroll to the bottom of the page and select the 2nd last menu	
-------------------------------------	--	--



Problem	Possible Causes	Suggested Action
---------	-----------------	------------------

Step 3 – Scroll to the bottom of the page and select the **2nd last menu**

Step 4 – Select desired language

Step 5 - Press the arrow button  to save your selection and return to the previous screen



Default / Factory Settings

To reset the flow meter to factory settings or default settings, you will need to manually adjust the following settings:

Setting	Default Value / comments
Settings	
Pipe Diameter	64.75
Unit Setting	Flow Unit Nm ³ /min Velocity Unit Nm/s Consumption Unit Nm ³ Temperature Unit °C
Gas Type	Air
Normalisation	Default Temperature 20°C Default Pressure 100kPA
RS485 Setting	Baud Rate 9600 Parity None Stop Bits 1 Response Delay 0 Device Address 1
Analog Setting	4-20mA Channel Velocity 4-20mA Scaling – Low 0 4-20mA Scaling – High 250 Cubic Meter/Pulse 5
System Settings	Screen Setting > Screen Timeout = 60s

Warranty

Compressed Air Alliance provides a 12-month warranty for all sensors. The warranty covers materials and workmanship under the stated operating conditions from the date of delivery. Please report any findings immediately and within the warranty time.

If faults occur during the warranty period Compressed Air Alliance will repair or replace the defective unit, without charge for repair labour and material costs but there is a charge for other services such as labour to remove or reinstall the instrument, transport and packing. Warranty repairs do not extend the period of warranty.

The following damage is excluded from this warranty:

- Improper use and non-adherence to the user manual.
- Use of unsuitable accessories.
- External influences (e.g. damage caused by vibration, damage during transportation, excess heat or moisture).

The warranty is cancelled when one of the following situations occurs:

- The user opens the measurement instrument without a direct request written in this manual.
- Repairs or modifications are undertaken by third parties or unauthorised persons.

The serial number has been changed, damaged or removed.

Other claims, especially damage occurring on the outside of the instrument (eg dents, marks), are not included unless responsibility is legally binding.

Calibration

The sensor is calibrated before delivery. The calibration date is printed on the certificate which is shipped with the sensor.

Flow Meters require calibration to remain accurate. The frequency of calibration depends greatly on the level of contamination within your system.

We recommend you calibrate the sensor every 2 years (provided the sensor is not exposed to relative humidity above 80%). Calibration is excluded from the product warranty. For more information, contact your dealer.



Strength

- We export to almost 100 countries.
- We have more than 2000 global customers.
- We can provide a total filtration solution.

- Filter-Online & Nordic Filtration offers a wide selection of filtration products for Domestic and Industrial Application.

- You can buy our products on our websites or by contacting us by phone or e-mail. Information about our products as well as brochures and manuals can be found on our websites:

www.filter-online.com for Domestic Products

nordicfiltration.com for Industrial Products

We distribute many of our products from our stock in Denmark. Some products are shipped from remote stock.



Filter-Online & Nordic Filtration ApS
Glasvænget 6
5492 Vissenbjerg
Denmark

Filter-Online
+45 70 40 42 22
info@filter-online.com
www.filter-online.com

Nordic Filtration
+45 72 25 10 00
info@nordicfiltration.com
nordicfiltration.com